

ISTRUZIONI PER LED DI POTENZA 350mA / 700mA

PER EVITARE DI DANNEGGIARE I FARETTI:

- Il collegamento di questo faretto è "IN SERIE": non tagliare i connettori o escludere il box jst (richiedere prolunghe all'occorrenza).
- Non collegare i faretti in tensione ma ad impianto scollegato.
- Non applicare interruttori/sezionatori sull'impianto secondario ma solo sul primario (tensione di rete).
- Per installazioni in zone soggette all'umidità utilizzare scatole di connessione IP68 per i collegamenti.
- E' consigliata l'installazione con i converter "LAMPO" ad una distanza di MAX 5mt tra converter e faretto

LA GARANZIA DECADE SE NON VENGONO RISPETTATI I SUDETTI PARAMETRI!

POWER LED 350mA / 700mA INSTRUCTIONS

TO AVOID DAMAGES TO SPOTLIGHTS:

- This item must be connected "in series": do not cut the connector or exclude the connection box (if necessary require the extension lead JST).
- Do not connect the spotlights under voltage.
- Do not apply switch on secondary system, but only on primary (main voltage).
- For installations in areas subject to humidity, use IP68 connection boxes.
- Is recommended to use "LAMPO" converters with the spotlights, with a MAX distance of 5mt between converter and spotlights

THE WARRANTY IS VOID IF NOT RESPECT THE ABOVE PARAMETERS!